

# Installation for 5.8GHz Wireless Outdoor Camera

## Model Number: ASC-4220



Please follow the installation instruction below:

1. Connect power adapter to camera.
2. Connect antenna to receiver.
3. Connect receiver to a TV/monitor with AV cable.
4. Connect power adapter to receiver.
5. Turn on TV/monitor power and select AV mode.
6. Set the channel of receiver same as camera by pressing the channel button continuously, and the picture shall displayed on your TV/monitor.
7. Adjust the brightness, contrast and color on your TV/monitor for best result.